


KEY

- 140 Auxiliary relay
- 141 Remote-control switch
- 142 Fuse carrier
- 143 Transformer
- 144 Socket connector
- 145 Plug connector

- 143
- 140
- 141
- 142
- 144
- 145



- 147

- 150
- 151

- 146
- 148
- 149

KEY

- 146 Speed switch
- 147 Reset button
- 148 Emergency button
- 149 Electric components box
- 150 Box cover
- 151 Box gasket

